

Installation Manual

Conceal Shower Set

***IMPORTANT:
READ BEFORE
INSTALLATION!***

D Pure Design

Pure-Design reserves the right to
modify the information contained in
this manual without notice.

Note: Detailed information is in accordance with the final product.




For users attention

DO NOT INSTALL IF YOU ARE NOT A PROFESSIONAL PLUMBER. THE WARRANTY WILL BE VOID, AND PURE-DESIGN WILL NOT BE LIABLE FOR ANY DIRECT OR INDIRECT DAMAGES, INJURIES, OR HARM IF THE PRODUCT IS NOT INSTALLED BY A CERTIFIED PLUMBER AND PROPERLY INSTALLED.

Do not disassemble the faucet main body, as it was assembled and fine-tuned to standard before leaving the factory; - To avoid damage to the faucet, flush the water pipes before installation. - After installation, make sure each joint safely sealed and does not leak. - Using conditions: working pressure at 0.5 - 1.0 MPa (including cold and hot water), the water temperature should be at least 4 °C and not more than 90 °C. - Make sure the hot and cold water pipes are connected correctly.

Tool


The tools below are required to complete the installation. Some may not be needed depending on the model of the faucet that you are installing. For additional information, check with your local hardware store on the requirements for your installation.(NOT PROVIDED)



Philips Screwdriver



Thread Seal Tape



Flashlight



Pliers



Adjustable Wrench






Safety Glasses

Specification


- 1.Lever style handle with temperature indicator on the trim plate
- 2.Handle operates upward through a 23° arc.The rotation angle of temperature is 100.Maximum hot through 50° in clockwise direction. Minimum cold through 50° in counterclockwise.
3. Adjustable temperature limit stop to control maximum hot water temperature.

Concealed Shower Installation




Mounting Depth

• Concealed Shower Series **WITHOUT MOUNTING BOX**




• Single function



• Multi functions



Before you begin




Helpful Hint:

Always use the supplied rubber washers on water supply connectors to prevent leaking. Also, always use an adequate amount of plumber's putty or thread sealing tape to prevent connectors from leaking.




One Functions Concealed Shower Installation






One Functions Concealed Shower Installation




Two Functions Concealed Shower Installation




Three Functions Concealed Shower Installation




Concealed Box Shower Series







*Some models come with a sliding bar instead of the simple hook



• Concealed Box Shower Series




Concealed Box Shower Installation




Shower Trims Installation steps

1




2



3



4



Product care

- It is recommended to use special products for chrome surfaces or soapy water to clean the surface.
- Wash off dirt with a soft sponge without rubbing. Dry the surface with a soft cloth.
- Do not use abrasive materials, rough paper or sharp objects.
- Do not use detergents containing acids or solvents or means for removing limescale.
- **Avoid using vinaigar to clean your faucets.**

Warranty conditions

The warranty begins at the time of purchase, on the date indicated on your invoice.

The warranty is valid only if the product has been installed according to industry standards, in compliance with the instructions, following the local plumbing code, **AND BY A LICENSED PLUMBER.**

Pure-Design will not be held responsible for any accidents, damages, losses, or inconveniences caused by the installation of the product or the product itself. Pure-Design only guarantees manufacturing defects.

THE WARRANTY IS NON-TRANSFERABLE; IT IS ONLY VALID FOR THE ORIGINAL PURCHASER.

The warranty and repair service may be refused in the following cases:

- Use of non-compliant parts or parts from other manufacturers.
- Supply of dirty water or limescale buildup.
- Non-compliant installation.
- Use of the product for purposes other than personal use. The warranty does not cover commercial use.
- Normal wear and tear of certain parts, such as the finish, aerator, sealing gaskets, etc.
- Use of abrasive, acidic, or other substances that may damage the faucet.
- Damage caused by negligent or improper use of the product, such as an impact on the faucet handle.
- Missing invoice or proof of purchase.
- Damage caused intentionally or due to negligence during storage, use, maintenance, installation, or lack of weekly inspection. This includes, but is not limited to, exposure to extreme temperatures (excessive cold or heat), thermal shocks, mechanical damage, etc.
- Failure to perform regular maintenance and replace wear parts, such as cartridges, sealing gaskets, and flexible connectors, as mentioned in this manual.

The warranty does not apply if the product has been damaged during transport after purchase, during storage, or after transport following a repair.

FAUCET TROUBLE SHOOTING:

Problem	Possible Cause	Corrective Action
Water does not shut off completely.	1.O-ring is not seated correctly or worn. 2.Cartridge may be defective.	1.Reseat or replace O-ring. 2.Replace cartridge
Leaks at waterline connection.	1.Worn or broken washer.	1.Replace washer.
Leaks from handle.	1.Cartridge may come loose. 2.Cartridge may be defective.	1.Reseat cartridge tight. 2.Replace cartridge.
Leaks at hose connection.	1.Hose connection is loose.	1.Tighten hose. 2.Replace hose.
Leaks at shower valve connection	1.Connection may come loose or not sealed completely. 2.Defective shower valve inlet or outlet connector.	1.Check connections. 2.Replace valve body.
Diverter knob does not work.	1.Diverter cartridge may be defective.	1.Replace cartridge.
Low flow	1.Check for water pressure problems. 2.Aerator may be dirty or clogged.	1.Clean or replace the aerator. 2.Remove water flow restrictor if available. 3.Install booster or pump (if applicable).

The warranty period for products

Cartridges are lifetime guaranteed and the rest of the product has a 5 years warranty.

The first year of the warranty includes the parts and labor. After the first year of ownership, the parts are included but not labor.

After 5 years, only the cartridge is covered by the warranty.

The warranty is limited to the conditions stated above in the warranty conditions section.

For more details about our warranty, please visit the "Warranty" section of our website:

www.pure-design.ca/meilleure-garantie-plomberie/

20231013

THANK YOU FOR YOUR CHOICE !